




1. NORMAL CONDITION (UNTRIGGERED)




2. TRIGGERING LOGIC SENSES FAULT AND RESPONDS




3. ACTUATOR INITIATED



4. SWITCH OPENING – SHUNT FUSE IS COMMUTATED INTO CIRCUIT



5. SHUNT FUSE MELTS AND INTERRUPTS



6. CIRCUIT CLEARED

